


# SHAD

## HONDA SH125 '17 KIT TOP HOSH17ST



**1** 400253  
12 cm



**2** 262139 x1



**3** 303045 x3  
Ø8



**4** 261277 x1  
Ø20 Ø11 x 25



**5** 304171 x1  
M8 x 65  
Din 7380



**6** 262140 x1



**7** 304201 x2  
M6 x 40  
Din 7380



**8** 303017 x4  
Ø6



**9** 302021 x2  
M6

### ! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

